Tubular A Arm Installation Instructions

(2005-2014 Mustang) Covering part #AA750,754,756

RECOMMENDED TOOLS:

Jack, Jack Stands, Lug wrench
15mm wrench
½" drive ratchet with 18mm deep socket and 21mm socket
Brass hammer

INSTALLATION:

1. Lift vehicle and support with stands positioned under the frame rails. Remove both front wheels/tires.

2. This step is not necessary for installation but makes the work area more accessible. Using a 18mm deep socket, loosen both outer tie rod ends. Knock both tie rods loose from the spindles using a brass hammer.

3. Using a 15mm wrench and 18mm socket, loosen and remove the spindle bolt that clamps the ball joint to the spindle.

4. Using a 18mm socket (21mm for 2010 and newer), loosen and remove the rear A-arm bolts on the K-member.

5. Using a 18mm socket, remove the front A-arm bolt on the K-member.

6. Remove A-arm.

7. With the A-arms installed, torque the following bolts to these specs:

8. Rear A-arm bolts – **125 FT/LBS.**

9. Do not tighten front A-arm bolt at this time.

10. Tie rod stud – **55 FT/LBS.**

11. Ball joint cross-bolt – **75 FT/LBS.**

12. Repeat steps 3-8 for the other side.

13. Re-install wheels/tires and allow the vehicles weight to rest on the suspension. The suspension is now loaded and the front bushings may be tightened to **95 FT/LBS**. If not on a service lift, this step may be done on ramps or blocks.

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.

Tubular A Arm Installation Instructions

(2005-2014 Mustang) Covering part #AA750,754,756

14. Grease all bushings on the A-arms with a grease gun. For optimal wear qualities and minimal noise, a full synthetic grease is recommended.

With all versions of these A-arms, a 4-wheel alignment is necessary after installation. Depending on vehicle ride height, doing so may require additional camber adjustment in the form of camber bolts. These are also available from BMR under part number FC001.



This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.

Tubular A Arm Installation Instructions

(2005-2014 Mustang) Covering part #AA750,754,756

Attention: Polyurethane and Delrin bushings must be properly lubricated with a full synthetic grease only

A full synthetic grease must be used to lubricate the inner sleeve via the grease fitting, contact points such as the outside faces of the polyurethane bushing must also be greased. We recommend Green Grease/Super Lube full synthetic grease for best results.



Do not install bushings dry. Lack of proper lubrication may cause squeaking, binding, premature wear, reduced performance, or damage to the bushings and related components. Bushings should be inspected and re-greased as needed, especially in harsh driving conditions or high-use applications.

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.