LTA629 – V2 Lower Trailing 'S' Arms

REQUIRED TOOLS:


- Hydraulic Jack or Lift
- Metric Socket Set and Wrenches


INSTALLATION:

1) Raise vehicle and secure on lift or jack stands.
2) Using a hydraulic jack or screw jack, support the lower control arm.
3) Using an open-ended wrench and socket as shown, loosen and unbolt the inner side of the 'S' arm.
4) Loosen and unbolt the spindle side of the 'S' Arm.
5) Using the factory hardware, install the new 'S' Arm in reverse order.

NOTE: You may have to pry and/or raise or lower the spindle in order to get the bolts started.

6) Torque fasteners to **125ftlbs.**
7) Grease the poly bushing with a **synthetic grease.**







WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicle's manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.

LTA629 – V2 Lower Trailing ‘S’ Arms

Attention: Polyurethane and Delrin bushings must be properly lubricated with a full synthetic grease only

A full synthetic grease must be used to lubricate the inner sleeve via the grease fitting, contact points such as the outside faces of the polyurethane bushing must also be greased. We recommend Green Grease/Super Lube full synthetic grease for best results.





Do not install bushings dry. Lack of proper lubrication may cause squeaking, binding, premature wear, reduced performance, or damage to the bushings and related components. Bushings should be inspected and re-greased as needed, especially in harsh driving conditions or high-use applications.

This product is an aftermarket accessory and not designed by the vehicle’s manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during installation or use of this product.